

HYT LCD Module

LCD Module












For evaluation and demonstration of the HYT modules

Benefits & Characteristics

- Easy usage
- Automatic address determination of connected sensor
- I²C address change possible
- External or internal power supply
- Automatic switchover (internal / external)
- Correction of humidity and temperature measurement values
- Permanent storage of the correction values

Illustration¹⁾



1) For actual size, see dimensions

Technical Data

Dimensions (L x W x in mm):	70 x 40
Humidity output signal:	0 V to 10 V (0 % RH to 100 % RH)
Temperature output signal:	0 V to 10 V (-40 °C to +125 °C)
Sampling time:	1 s
Supply voltage:	3 V by internal CR2032 (battery not included) or 5 V by external supply, reverse polarity protected, automatic switchover
Current consumption:	< 4 mA
Supported sensor:	HYT 271 or HYT 221
Digital interface:	I ² C
Display:	LC-display with 2x8 characters
Maximum output load:	10 mA

Order Information¹⁾

	IST_HYT_LCDmodul
Order code	600.00054

¹⁾ The LCD-Module does not contain any sensors. The sensors must be ordered seperately.

DHLCD-Module_E2.2 1/4



HYT LCD Module





LCD Module





For evaluation and demonstration of the HYT modules

Additional Documents

	Document name:
Datasheet:	DHHYT271_E
Datasheet:	DHHYT221_E
Datasheet:	DHHYT939_E
Application note:	AHHYTM_E







Innovative Sensor Technology IST AG, Stegrütistrasse 14, CH-9642 Ebnat-Kappel, Switzerland, Phone: +41 (0) 71 992 01 00 | Fax: +41 (0) 71 992 01 99 | E-mail: info@ist-ag.com | Web: www.ist-ag.com



Application Note Humidity Module








LCD Module for HYT 271




The Hygrochip LCD module is an easy to use demonstration and evaluation kit for HYT sensors. The measured values of the connected sensor can be displayed on the display. If an external power supply is used the measured values are also available on the analog outputs.

1 Pin Designation

Тор



Bottom



AHHYTM_E2.2 3/4



Application Note Humidity Module









2 Description of Operation

After power on, the module shows the following information for 2 seconds:

HYT 271 – Module www.ist – ag.com

After that it changes to the measurement mode and shows the values of relative humidity and temperature.

Humidity 54,3 % Temperat 23,7 °C

The following configuration options are available in addition to the measured values:

CONFIGURATION

Address 0xHH (0x00 - 0x7F)

2. CONFIGURATION

Corr-Temp. 0.0K (-1,0K - 1,0K)

CONFIGURATION

Corr-Humid 0.0% (-1,0% - 1,0%)

Switching between the standard and configuration menus is possible by use of the UP and DOWN buttons.

By pressing the OK button into a configuration menu the software goes into the input mode. This mode is shown by the cursor and blinking of the last character. In the input mode the function of UP / DOWN will be changed to +/-. The value can be changed into the limits by pressing the +/- buttons.

The new value is stored by pressing the OK button.

By pressing the ESC button the entered value is rejected and the software leaves the input mode.





